





BUTTERFLY CHENILLE EMBROIDERY MACHINE CONTROL SYSTEM FAST MANUAL

-QUICK START-


A: Input Designs




B: Choose a Design



C: Manual modification method




D: Position Idling



G: Design border operation



I: Manual Trimming



E: Return to start point




H: Return to stop point



J: Manually shifting head



F: Set color changing order








BUTTERFLY CHENILLE EMBROIDERY MACHINE CONTROL SYSTEM FAST MANUAL

-QUICK START-



K: Set cyclic embroidery

 → 【②Common Parameter】 → 【①Embroidery Assistant Parameter】 → 【②To Do Cyclic Emb.】 change to "Yes" → 



L: Manual select chain or loop stitch

 → 【③Manual Shift Stitch Form】 →  → Select stitch form → 

M: Setting another start

 → 【⑤Setting Another Start】 → Move frame to offset point → 



N: Close Bad head

 → 【⑦ON/OFF Machine Head】 →  → Use “◀ ▶” and number key to select head for activation → Perform the operation

O: Thread-loosing Position Adjustment

 → 【⑧Thread Loosing Posi. Adj.】 →  → Adjust Thread-loosing Position → 

P: Manual Needle Height Adjustment

 → 【⑨Needle Height Adj.】 →  → Input Set Value → Perform the operation

Q: Manual Color-Changing

Press number key to input needle position

R: Let Needle Down

 → 【④Stitch Stop Down】 → 

Note:



as Function Shift